



Edition:  
Push button

Edition:  
Vibrator button only one  
Drive with potentiometer PA 13 version  
Drive with potentiometer PA 15 possible




Edition:  
Rocker switch  
(installed Pos. 3, 4 inapplicable)



Edition:  
Sliding switch installed Pos. 13, 14  
installed Pos. 1, 2, 4, 6 inapplicable  
Drive with potentiometer PA 12 direction 11 - 12 installed Pos. 11, 12  
PA 11 inapplicable  
Push button with 2 steps ZD installed Pos. 11 - 12  
PA 11, 12 inapplicable

**Example for type-sign**

- Palm grip
- Push button
- Rocker switch
- Lever switch



- Special please describe
- Drive with potentiometer PA 13
- Drive with potentiometer PA 11
- Sensor button